

Rihn Aircraft Corp.

DR-107- One Design

Drawing List

| | | |
|----|--------------|---|
| 1 | DR7-1-000 | General Arrangement |
| 2 | DR7-1-001 | Paint Scheme |
| 3 | DR7-1-110 | Fuselage Structure |
| 4 | DR7-1-111 | Basic Fuselage Structure |
| 5 | DR7-1-112 | Basic Fuselage Structure |
| 6 | DR7-1-113 | Basic Fuselage Structure (Bill of Material) |
| 7 | DR7-1-114 | Firewall |
| 8 | DR7-1-115(1) | Fuselage Side Panel |
| 9 | DR7-1-115(2) | Fuselage Side Panel (Front) |
| 10 | DR7-1-116 | Fuel Tank Fairing |
| 11 | DR7-1-117 | Roll Over Safety Bar |
| 12 | DR7-1-118(1) | Cockpit Coming |
| 13 | DR7-1-118(2) | Belly Pan (Rear) |
| 14 | DR7-1-118(3) | Belly Pan (Forward) |
| 15 | DR7-1-119 | Former, Side and Bottom |
| 16 | DR7-1-120 | LDG Mounts, Wing Mounts |
| 17 | DR7-1-121(1) | Fuselage Standoffs, Fuel tank Mount |
| 18 | DR7-1-121(2) | Fuselage Stringer Standoffs |
| 19 | DR7-1-122 | Cockpit, Seat & Turtledeck |
| 20 | DR7-1-123 | Fuselage Stringers |
| 21 | DR7-1-125 | Fin & Rudder |
| 22 | DR7-1-126(1) | Tail Cone Fairing |
| 23 | DR7-1-126(2) | Tail Cone Fairing |
| 24 | DR7-1-126(3) | Tail Cone Fairing |
| 25 | DR7-1-127 | Cowl Assembly |
| 26 | DR7-1-128 | Sliding Canopy Assembly |
| 27 | DR7-1-130 | Fuel system |
| 28 | DR7-1-131 | Fuel Tank Ends-Flat Patt |
| 29 | DR7-1-144 | Pitot Static System |
| 30 | DR7-1-145 | Canopy Loft |
| 31 | DR7-1-146 | Instrument Panel |
| 32 | DR7-1-147 | Former, Fuselage Turtle Deck |
| 33 | DR7-1-148 | Turtle Deck Assembly |
| 34 | DR7-1-149 | Wing Root Fairings |
| 35 | DR7-1-150(1) | Longitudinal Control System |
| 36 | DR7-1-150(2) | Longitudinal Control System |
| 37 | DR7-1-151 | Directional Control |
| 38 | DR7-1-152 | Tailwheel Spring & Tailwheel |
| 39 | DR7-1-160 | Horizontal Tail Structure |

| | | |
|----|--------------|--|
| 40 | DR7-1-161 | Horizontal Tail Installation Details |
| 41 | DR7-1-162 | Tail Brace wires-Lugs and Installation |
| 42 | DR7-1-201 | Engine Mount |
| 43 | DR7-1-301 | Basic Wing Structure –Douglas Fir Spar |
| 44 | DR7-1-302 | Wing Spanwise Members –Douglas Fir Spar |
| 45 | DR7-1-303 | Wing Skin |
| 46 | DR7-1-304 | Wing Ribs- Fir Spar (W.S 12.5, 15 & 24) |
| 47 | DR7-1-305 | Wing Ribs- Fir Spar (W.S 36 & 48) |
| 48 | DR7-1-306 | Wing Ribs- Fir Spar (W.S 60 & 72) |
| 49 | DR7-1-307 | Wing Ribs- Fir Spar (W.S 84 & 96) |
| 50 | DR7-1-308 | Wing Tip Rib |
| 51 | DR7-1-309 | Aileron Mount Controls Wing Attach |
| 52 | DR7-1-310 | Aileron Assembly |
| 53 | DR7-1-311 | Wing Tip |
| 54 | DR7-1-312 | Aileron Spades |
| 55 | DR7-1-313(1) | Wing Installation |
| 56 | DR7-1-313(2) | Wing Installation |
| 57 | DR7-1-901 | Basic Wing Structure –Spruce Spar |
| 58 | DR7-1-902 | Wing Spanwise Members –Spruce Spar |
| 59 | DR7-1-904 | Wing Ribs- Spruce Spar (W.S 12.5, 15 & 24) |
| 60 | DR7-1-905 | Wing Ribs- Spruce Spar (W.S 36 & 48) |
| 61 | DR7-1-906 | Wing Ribs- Spruce Spar (W.S 60 & 72) |
| 62 | DR7-1-907 | Wing Ribs- Spruce Spar (W.S 84 & 96) |